

INSTRUCTIONS & WARRANTY

open zip
before folding



unfolding &

folding to
a flat staple



2 Options for packing and taking away:

1) regular flat
folded

This is the normal folded state and we recommend it:
Faster, easier and avoids crinkles on iCap and on the front Cover.



2) extra small
twisted

Optional, if required, the folding process can be continued with twisting iCap



On the back side
you can see how to
twist your iCap



Beware computer of OVERHEATING. Open FLAPS and FRONT COVER to VENTILATE !!

24 months warranty

iCap products are designed and built to be free of manufacturer and material defects and carry a limited 24 months warranty.

The warranty applies only when the products have been put to the use intended and it does not cover bended wires and broken connectors, due to inappropriate folding. In general, it does not cover accidental damage, misuse, improper care or alteration.

Over and above the warranty terms we are truly committed to your satisfaction with our products and service. If at any time you are not satisfied please contact us.

help.
notebooktent
.com



iCapTM

Option 2

for taking iCap with you:


Extra small twisted !

PRESS & TWIST 180°

PRESS hands to each other
while TWISTING 180°:
(a full opposite rotation).

Ensure that always ALL 4 LAYERS
follow the twist!

3 CIRCLES will be formed:
The middle circle (3)
must be EMBEDDED INSIDE
the outer circles (1 and 2).
Steer the middle circle with your fingers and
the palm of your hand
to get clear BETWEEN the 2 outer circles.
If it goes above or under them,
it will get entangled.



Twisting is simple but should be done properly, otherwise the wires could get bent.

If you have any problems with the operation of your iCap, please call us or write to us. We'll contact you fast !

Wishes and ideas about functionality are very welcome.

Please look at the
video before twisting



help.
notebooktent
.com

